



Tech Tip

May 2023

TWE Odyssey Air Handler with Variable Frequency Drive(VFD) single or 2 speed operation



Identifying via model number the unit will be equipped with a Variable Frequency Drive(VFD) see the 15th digit of the model number which will either be **C** or **D**.

If the 15th digit is D; 2 stage airflow/Single zone VAV. **Mod Bus and IMC communication wiring will be needed, twisted shielded 18 AWG.**

Depending on control, verify in Symbio configuration space controller setting for appropriate control - zone sensor or conventional.

If there is a need to change a unit that has the 15th digit as D to use as a single or 2 stage airflow without communication wire. This will require wiring harness change as well as configuration changes to VFD parameters.

Good practice before installation date: Know the models you will be installing, if any changes need to be done and how will the system be wired with what is available on Jobsite.

[Click here for link to Light Commercial Help Center](#)

TWE Air Handler with Symbio	
Digit 15 – Controls	
1 = Constant Volume	
C = 2 Stage Airflow (Electromechanical Condenser Only)	
D = 2 Stage Airflow/Single Zone VAV (Symbio Condenser Only)	

C = VFD - Start + Full Speed Binary Inputs
 D = VFD - Mod Bus + IMC Communication
 2 twisted / shielded pair

TRANE PURPLE WIRE Recommended

Part Number	Business Unit	Description
CAB01568	US Manufacture	CABLE; COMLINK CABLE WITH A PVC JACKET, 18/1 PR, STRANDED SHIELD, 25PF PLENUM, 100 FOOT LENGTH

Part Number	Business Unit	Description
CAB01569	US Manufacture	CABLE; COMLINK CABLE WITH A PVC JACKET, 18/1 PR, STRANDED SHIELD, 25PF PLENUM, 1000 FOOT LENGTH

Field Service Representative Contact

SW FL 239-277-0344; Option 3


SE FL 954-421-7133; Option 2

N FL 844-358-7263; option 2

Tech Tip

May 2023

TWE Odyssey Air Handler with Variable Frequency Drive(VFD) single or 2 speed operation



2 speed Operation without communication wiring -

You will need one of the following harnesses

Relay Board(RB) to drive connector [length] - required

WIR010190 or WIR010096[87"] or WIR10183[124"]

Connector to drive - optional

WIR010185

Harness connection to VFD as shown. Terminals 12, 18, 50 and 53 are used with a **jumper** between terminals 12 and 27.

Verify Symbio configuration:

System Type
CVZT

Following changes need to be made to the parameters of the VFD TR150.

- A. Change 0-40 from [0] Disabled to [1] Enable
- B. Change 3-15 from [11] local bus reference to [1] Analog Input
- C. Change 5-10 from [11] No Operation to [8] Start
- D. Change 5-12 from [0] No Operation to [2] Coast Inverse
- E. Change 8-01 from [2] Control Word Only to [0] Digital & Control Word
- F. Change 8-02 from [1] FC Port to [0] None
- G. Change 8-04 from [2] Stop to [0] Off
- H. Verify 4-12 is set to [25 Hz]
- I. Verify 4-14 is set to [60 Hz]
- J. Verify 6-10 is set to [0.07V]
- K. Verify 6-11 is set to [10.00V]
- L. Verify 6-14 is set to [25 Hz]
- M. Verify 6-15 is set to [60 Hz]

4-12 Motor Speed Low Limit [Hz]
4-14 Motor Speed High Limit [Hz]

[Click here to view/download - Odyssey with Symbio Controls wiring and Startup – SS-SVN016*- EN reference pages 12-13](#)

TWE Odyssey Air Handler with Variable Frequency Drive(VFD) single or 2 speed operation

Navigating VFD Keypad

1	Parameter number and name.
2	Parameter value.
3	Set-up number shows the active set-up and the edit set-up. If the same set-up acts as both active and edit set-up, only that set-up number is shown (factory setting). When active and edit set-up differ, both numbers are shown in the display (set-up 12). The number flashing, indicates the edit set-up.
4	Motor direction is shown to the bottom left of the display – indicated by a small arrow pointing either clockwise or counterclockwise.
5	The triangle indicates if the keypad is in status, quick menu or main menu.

Table 1.13 Legend to Illustration 1.17

B. Menu key

Use the menu key to select between status, quick menu or main menu.

The keypad is divided into four functional sections.

- A. Alphanumeric display
- B. Menu key
- C. Navigation keys and indicator lights (LEDs)
- D. Operation keys and indicator lights (LEDs)




Illustration 1.17 Keypad

C. Navigation keys and indicator lights (LEDs)


6	Com LED: Flashes when bus communication is communicating.
7	Green LED/On: Control section is working.
8	Yellow LED/Warn.: Indicates a warning.
9	Flashing Red LED/Alarm: Indicates an alarm.
10	[Back]: For moving to the previous step or layer in the navigation structure
11	[▲] [▼] [▶]: For maneuvering between parameter groups, parameters and within parameters. Can also be used for setting local reference.
12	[OK]: For selecting a parameter and for accepting changes to parameter settings

Change 0-40 from [0] Disabled to [1] Enable - Hand on
This will allow control of the blower via Hand on button on Keypad

D. Operation keys and indicator lights (LEDs)

13	[Hand On]: Starts the motor and enables control of the frequency converter via the keypad. NOTICE Terminal 27 Digital Input (5-12 Terminal 27 Digital Input) has coast inverse as default setting. This means that [Hand On] does not start the motor if there is no 24 V to terminal 27. Connect terminal 12 to terminal 27.
14	[Off/Reset]: Stops the motor (Off). If in alarm mode the alarm will be reset.
15	[Auto On]: frequency converter is controlled either via control terminals or serial communication.

ALWAYS VERIFY VFD PARAMETER SETTINGS PRIOR TO OPERATING BLOWER



Tech Tip

May 2023

TWE Odyssey Air Handler with Variable Frequency Drive(VFD) single or 2 speed operation



Open loop and VFD Electrical Overview

The built-in wizard menu guides the installer through the set-up of the frequency converter in a clear and structured manner to set-up an open loop application. An open loop application is here an application with a start signal, analog reference (voltage or current) and optionally also relay signals (but no feed back signal from the process applied).




Illustration 1.18 Open Loop Application

The wizard will initially be shown after power-up until any parameter has been changed. The wizard can always be accessed again through the quick menu. Press [OK] to start the wizard. Press [Back] to return to the status screen.





Illustration 1.16 Basic Wiring Schematic Drawing



Tech Tip

May 2023

TWE Odyssey Air Handler with Variable Frequency Drive(VFD) single or 2 speed operation



Temporary operation no comm wire without wire harnesses – single speed.

You will need to use a relay and make changes to specific parameters.

- A. Install jumper between 12 and 27 terminal at VFD
- B. Change 0-40 from [0] Disabled to [1] Enable
- C. Change 3-15 from [11] local bus reference to [1] Analog Input
- D. Change 5-10 from [11] No Operation to [8] Start
- E. Change 5-12 from [0] No Operation to [2] Coast Inverse
- F. Change 8-01 from [2] Control Word Only to [0] Digital & Control Word
- G. Change 8-02 from [1] FC Port [0] None
- H. Change 8-04 from [2] Stop to [0] Off
- I. Change 4-12 From [25 Hz] to desired speed in Hz [45-60 Hz]
- J. Verify 6-10 is set to 0.07V
- K. Verify 6-11 is set to 10.00V


If using electric heat, with no options board. Symbio configuration for primary heat needs to be set to not installed.

Verify Symbio configuration: System Type CVZT

J10 – 1&2 will need to be wired, to power relay board

J5 – 4 will need to be wired for fan call

J5 – 7 will need to be wired for electric heat call



Tech Tip

May 2023

TWE Odyssey Air Handler with Variable Frequency Drive(VFD) single or 2 speed operation



Temporary operation no comm wire without wire harnesses – 2 speed.

You will need to use a relays and make changes to specific parameters.

- A. Install jumper between 12 and 27 terminal at VFD
- B. Change 0-40 from [0] Disabled to [1] Enable
- C. Change 3-15 from [11] local bus reference to [1] Analog Input
- D. Change 5-10 from [11] No Operation to [8] Start
- E. Change 5-12 from [0] No Operation to [2] Coast Inverse
- F. Change 8-01 from [2] Control Word Only to [0] Digital & Control Word
- G. Change 8-02 from [1] FC Port [0] None
- H. Change 8-04 from [2] Stop to [0] Off
- I. Verify 4-12 is set to 25 Hz
- J. Verify 4-14 is set to 60 Hz
- K. Verify 6-10 is set to 0.07V
- L. Verify 6-11 is set to 10.00V
- M. Verify 6-14 is set to 25 Hz
- N. Verify 6-15 is set to 60 Hz

4-12 Motor Speed Low Limit [Hz]
4-14 Motor Speed High Limit [Hz]

