

# April 2023 Tech Tip

## Accessory and External Switch wiring and configuration for Link

The only way to Configure an Accessory and/or an External Switch is through the Tech App.

External Switch have source power 24vAC

The External Switch is used for 3<sup>rd</sup> Party condensate switches and/or smoke detectors

Accessory 1 & 2 are Dry Contacts

Source Voltage with need to be provided for a TFD/AFD, External Dehumidifier, Ventilation, etc.

