


Clii Sensor Varification Check J1

XV Clii sensors located on J1 can be viewed in the monitor menu in th CDA, Communicating Display Assembly.

To access Push and Hold the Up and Down Arrows
SIMUTANIOUSLY until the screen changes to MONITOR MENUE
(approx. 15 seconds)

Press Down to System
Press Right COMP DEMAND



Press UP until you see DOME TEMP
Continue to press the Up arrow for all of the reporting sensor readings



All of the sensors located on J1 have a Control Voltage of 3.2vdc

The Suction Pressure Transduce, located on J1 has a Control Voltage of 4.99vdc

